

- |   |  |
|---|--|
| 1. HF-5 S/S OUTER DRIVE FRAME               | 16. PILLOW BLOCK BEARING (3110-101)          |
| 2. HF-5 STEEL INNER DRIVE FRAME             | 17. DRIVEN SPROCKET (3020-532)               |
| 3. FT-BA LEGS w/ADJUSTABLE FEET             | 18. HBR-5 BELT RETAINER** (3910-150)         |
| 4. HTE-P S/S REMOVABLE FRAME ENCLOSURE      | 19. RETAINER CENTER BEARING** (3910-150)     |
| 5. START / STOP STATION*                    | 20. S/S DRIVE SHAFT /10 " BELT (9510-130)    |
| 6. SHELCONTROL PANEL & ENCLOSURE            | 21. RETAINING COLLAR*** (5330-900)           |
| 7. MAIN CIRCUIT BREAKER                     | 22. AWS - 25 WASH TANK **** (5700-900)       |
| 8. SERVICE "J" BOX                          | 23. WASH TANK DOOR ASSEMBLY (5700-901)       |
| 9. MOTOR SPLASH SHIELD (5700-310)           | 24. WASH TANK SCRAP BASKET**** (5700-011)    |
| 10. CONVEYOR DRIVE MOTOR (CALL TO VERIFY)   | 25. DRAIN PIPE                               |
| 11. SPEED REDUCER (CALL TO VERIFY)          | 26. SPROCKET SPACER WASHER**(3910-150)       |
| 12. DRIVER SPROCKET (3020-520)              | 27. WASH TANK BOOT SEAL*** (5330-900)        |
| 13. DRIVE ROLLER CHAIN (3040-250)           | 28. BR-3 MONORAIL (3910-300)                 |
| 14. CHAIN TENSIONING IDLER ASSY. (3020-899) | 29. WASH TANK DRAIN PAN CHUTE (5900-111) PVC |
| 15. DUAL BELT SPROCKETS (3020-700)          | 30. REVERSIBLE WEAR PLATE** (3910-150)       |

NOTES;

\* = NOT SHOWN

\*\* = PART OF HBR-5 ASSY.

\*\*\* = PART OF SEAL KIT ASSY.

\*\*\*\* = PART OF WASH TANK ASSY.



2081 S. HELLMAN AVE. #J ONTARIO, CA. 91761

(909) 947- 4877

FAX (909) 947-1083